

Order #XXXXX VK-1853 Sunrise Table Top

Item	QTY	Description
1	1	44" Vertical Extrusion
2	1	44" Vertical Extrusion
3,3A	1,1	31.5" Horizontal Extrusion
4,4A	1,1	31.5" Horizontal Extrusion
5,5A	1,1	25.197" Horizontal Extrusion
6,6A	1,1	4.5" Vertical Extrusion
7,7A	1,1	26.5603" Curved Horizontal Extrusion

Steps:


- 1) Connect horizontals [3 to 3A] and [4 to 4A]. See Straight detail.
- 2) Connect verticals [1] and [2] with horizontal assemblies. See Corner detail.
- 3) Connect header assemblies [5/6/7] and [5A/6A/7A] together.
- 4) Attach assembled header to [4/4A]. using bolts, making sure Velcro is facing to BACK.
- 5) Connect Header graphic to Velcro.
- 6) Attach feet to verticals [1] and [2]. See Foot Attachment detail.
- 7) Apply graphic to assembled frame. See SEG Graphic Installation detail.





Keep extrusions [5/6/7] and [5A/6A/7A] assembled when packing.


SEG Graphic Installation



It is important to first insert graphic into each alternate corner then to the sides of the frame. If this is not done, graphic will not fit into the frame correctly.



Step 1
Insert corner A. Turn edge of graphic so silicon welt is perpendicular to face of graphic. Insert narrow side of welt with fabric to outside into the channel. Repeat for other side of this corner.




Step 2
Repeat Step 1 for opposite corner C, then insert corner B, followed by corner D, to complete the installation of the corners


Graphic Ren



Step 3
Once all corners are inserted, press one silicon edge into channel from corners and work toward the center. Make sure welt is fully inserted into channel. Continue until all sides are done. Smooth out edges of graphic.



To remove the graphic from the frame, locate the fabric pull tab. Gently pull up on the tab to remove the fabric.





General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




MARNING



Spline Connection



Base Plate & Extrusion Connection








DO NOT USE POWER TOOLS




LADDERS OR LIFTS MAY BE REQUIRED



ALL CONNECTIONS MUST BE TIGHTLY SECURED



Extrusion & Lock Connection



Engaged Lock



Top View of Each Level

